



How to replace Wago main module (bus-coupler) 750-352 750-362

**Warning! Turn off power supply before you execute the following operations
Only trained and authorized staff is allowed to execute below operations.**

Remove

To remove the Wago bus-coupler (750-352 or 750-362) follow these steps:

1. turn off electrical supply of the test bench
2. unplug ethernet cable from Wago bus-coupler
3. use appropriate small screwdriver




4. unwire the two wires which provides the electrical supply to the Wago bus-coupler





5. release the orange locking disc, using a screwdriver (see "loosen" in the drawing)
6. pull the orange coloured unlocking lug (see "Release lug" in the drawing)
7. lift the unit to remove from the rest of the modules



[Watch Youtube video >>](#)

Installing a pre-programmed Wago bus-coupler (750-352 or 750-362)

1. turn off electrical supply of the test bench
2. press the Wago bus-coupler module into the I/O units until it snaps into the carrier rail
3. lock the orange locking disc, using a screwdriver (see "fix" in the drawing)
4. push the orange coloured locking lug down (see "Release lug" in the drawing)
5. wire electrical supply into Wago bus-coupler
6. plug ethernet cable into Wago bus-coupler

[Watch Youtube video >>](#)

Programming a new Wago bus-coupler (750-352 or 750-362)

1. turn off electrical supply of the test bench
2. press the Wago bus-coupler module into the I/O units until it snaps into the carrier rail
3. lock the orange locking disc, using a screwdriver (see "fix" in the drawing)
4. push the orange coloured locking lug down (see "Release lug" in the drawing above)
5. set the first DIP switch of the Wago bus-coupler to ON (by default they are all OFF)
6. set the ethernet card of the PC with the IP address 192.168.1.100
7. wire electrical supply into Wago bus-coupler
8. plug ethernet cross cable between Wago bus-coupler and PC ethernet card
9. open a browser and type the address 192.168.1.1
 1. User: admin



2. Password: wago
10. in the menu TCP/IP assign the desired IP address (the one used previously by the Wago bus-coupler and labelled on it), usually 192.168.100.101 (o 10.101.10.101)
11. in the menù Port, select “use IP from EEPROM”
12. unwire electrical supply from Wago bus-coupler
13. set all DIP switches of Wago bus-coupler to OFF
14. wire electrical supply into Wago bus-coupler
15. with the browser ensure the address 192.168.1.1 is no more reachable
16. set the ethernet card of the PC with the previous settings, usually 192.168.100.100 (or 10.101.10.100)
17. ensure that Wago I/O modules are reachable (via browser or ping) with the newly assigned address (192.168.100.101 or 10.101.10.101)