




How can I correct runtime error VISA Read in GPT-9000?



The mentioned problem is very likely to be originated by an unstable/defective communication between the PC of the test bench and the electric safety tests unit.

To troubleshoot this problem read out chapter “**Serial communication problem**” of the FAQ [Electric Safety Test \(EST\) unit troubleshooting](#)