



What is the procedure for test bench shutdown and startup?

Shutdown procedure

Operation	By means of
open water drains and evacuate water	use diagnostic program and open suitable valves
close all software programs	use push buttons or mouse
turn off the PC	use push buttons or mouse
turn off electricity	main switch of the electric cabinet
close compressed air inlet	manual valve
close water inlets	manual valves
close gas inlets (when applicable)	manual valves

Startup procedure

Operation	By means of
turn on electricity	main switch of the electric cabinet
PC will turn on automatically	//
open compressed air inlet	manual valve
open water inlets	manual valves
open gas inlets (when applicable)	manual valves
run the software program	automatic start or icon on the desktop