



What is the procedure for test bench shutdown and startup?

Shutdown procedure

For steps marked as “Necessary” follow the exact order as they are listed

Step	By means of	Necessary / Suggested
open water drains and evacuate water	use diagnostic program and open suitable valves	suggested
close all software programs	use push buttons or mouse	necessary
turn off the PC	use push buttons or mouse	necessary
turn off electricity	main switch of the electric cabinet	necessary
close compressed air inlet	manual valve	suggested
close water inlets	manual valves	suggested
close gas inlets (when applicable)	manual valves	suggested

Startup procedure

Step	By means of
turn on electricity	main switch of the electric cabinet
PC will turn on automatically	//
open compressed air inlet	manual valve
open water inlets	manual valves
open gas inlets (when applicable)	manual valves
run the software program	automatic start or icon on the desktop