



## What is the uncrating procedure?

STEP	NOTES
<p><b>1. Remove the top of the crate</b></p>	<p>Use an electric screwdriver to remove all screws along the perimeter. Do not remove nails.</p> 
<p><b>2. Open this side of the crate (the side where the label "Unpacking Procedure" is screwed)</b></p>	
<p><b>3. Use a forklift to take test bench out of the crate</b></p>	<p>Ensure forks are aligned with black arrows (on yellow background).</p> 
<p><b>4. Read User Manual for following steps</b></p>	<p>When available read <b>Installation Guide</b> first</p>